

Tempotest

Material, Maintenance & Storing



Material

- Teflon-coated, anti-soiling acrylic fibre (solution-dyed)
- UV-resistant

Maintenance & cleaning

In case of food or drink spills, wash the spot immediately with warm soapy water and allow the pillow to dry in an upright position.

For more thorough cleaning, all pillow covers can be removed and machine-washed at 30°C. Make sure the cover is completely dry before putting the pillow into the cover. All covers are machine washable at 30°C. For stubborn stains or built-up soil, carefully wash with a recommended stain remover, such as Vanish (Va-nish Oxi Action).

Storing

Pillows without QuickDryFoam® are NOT waterproof. Please follow these instructions for storing:

- 1) It is best to store the pillows indoors.
- 2) Alternatively, they can be stored in watertight, ventilated cushion box on a covered terrace, patio or carport, protecting them from the elements while ensuring proper ventilation.

Variant



Taupe (Y36)

For further questions, please contact info@cane-line.com or visit Cane-line.com

Cane-line®
- life made comfortable